

GET FAMILAR WITH YOUR DEVICE



AIR PRESSURE STATION

For the best possible ride experience, accurate air pressure is a necessity. Use this device with your current air compressor for convenient and precise pressure on any of your bicycles. Tubeless tire seating and initial

inflation setup buttons, as well as up to three presets available for even faster and easier setups. One button inflation to take advantage of the time you have and start your rides off quickly, with exact pressure.

DECREASE AIR PRESSURE

SET PRESSURE PRECISELY


Accurate within 0.5% PSI/BAR

AIR IN, AIR OUT

PLUG IN FOR AIR COMPRESSOR & INFLATION HOSE

Attach your air compressor to the "AIR IN" port, and your inflation hose to the "AIR OUT" port.

UNIT OF MEASUREMENT SELECTION



AIR IN

AIR OUT

AIR PRESSURE PRESETS

PRESET UP TO 3 PREFERED AIR PRESSURE SETTINGS

Dial in preferred tire pressure, press and hold preset button for 3 seconds to set.

INCREASE AIR PRESSURE


SET PRESSURE PRECISELY

Accurate within 0.5% PSI/BAR

INITIAL TIRE INFLATION

BURST OF AIR FOR INITIAL INFLATION

Press once for 3 Bursts of air to quickly begin inflation and tire seating. Press and hold to turn off device.



AIR CHUCK

SEE BACK SIDE OF THIS CARD

3

2


1

AIR CHUCK GUIDE

OPEN




CLOSED



UNIT INCLUDES 2 INLET FITTINGS:

*Use fitting that matches your supply hose attachment.
(prep threads w/ Teflon tape)*

AUTOMOTIVE



INDUSTRIAL



WALL MOUNT INSTALLATION GUIDE:

